

EPIC Remote Control User Guide

- 1** Set Top Box Power
- 2** Guide Search
- 3** Full Screen/Mini Screen
- 4** Guide Options
- 5** CDVR Fastforward/Rewind
- 6** Play/Pause
- 7** CDVR Skip Forward/Backward
- 8** Navigate
- 9** Back
- 10** Volume
- 11** Keypad
- 12** TV Power
- 13** Mute
- 14** Guide Next Day
- 15** Guide Previous Day
- 16** Stop
- 17** Guide Shortcut
- 18** Select
- 19** Previous Channel
- 20** Page Change/Channel Change
- 21** Guide Options and Info
- 22** Closed Captioning

